





## Apply to Floor




### 1. PREPARE FLOOR

Clean and dry the floor so Grippy Mat will properly adhere.



### 2. STICKY SIDE DOWN


Remove pre-cut mat from the roll, then position the adhesive side toward the floor.



### 3. SMOOTH OUT

Smooth out mat with hands or a flat edge, pushing out air bubbles, and press into place.


## Care & Maintenance



### WEAR AND TEAR

If the adhesive on mat edges or corners lift, use a utility knife to remove the weakened piece of mat.

## Cleaning



### EVERYDAY CLEANING

Leave mat in place while you sweep, mop, scrub or vacuum according to your protocols. Daily cleaning will not affect custom-printed mats.



### DEEP CLEANING

Deep clean and remove stains with a wet vac, extractor or Rug Doctor® — this will not affect custom-printed mats.



### HANDLING EXCESS WATER

Excessive water, rain, snow or slush should be removed using a wet-vac, Rug Doctor® or extractor for best performance.

## Removal



### REMOVAL & CHANGEOUTS

Replace mat when it shows obvious signs of wear or a weakened bond to the floor. Peel up a corner and pull in a smooth motion.

